

# G6 Superhomes



"Luxury meets the next Gen"

## Please remember following instructions during installation of touch switches.

- 1) Space for the power module in the metallic box or else 4 wires should be available near the high load device. (2.5 to 3 inch depth when power module)
- 2) Curtains should be direct. Don't provide an on/off switch on the board.
- 3) Router should be direct, if an inverter is available then power it through the inverter.
- 4) The board should be powered through the inverter if there are devices which are to be powered through the inverter.
- 5) Wiring needs to be done with power off.
- 6) Handle with care while removing superswitch from the base plate.
- 7) Warranty would be void if the hologram sticker is off.
- 8) Line and neutral wires should be connected in orange connectors or terminals.
- 9) Switches should be connected in green connectors.
- 10) Superswitch should be removed in the same way as you remove Norysis accessories.

